

# lobster elite™

grand five limited edition owner's manual



play more. win more.®

## TO OUR CUSTOMERS

**Thank you** for purchasing a Lobster ball machine. Please read this owner's manual in its entirety before operating your Lobster ball machine. These instructions were written to ensure your safety and to protect the machine.

## CHECK FOR DAMAGE

Inspect your machine for damage. The machine may appear undamaged externally, but internal parts could be damaged. Test all of the machines functions.

## SAVE THE ORIGINAL SHIPPING BOX

The original box and inserts should always be used if it is necessary to ship the machine back to the factory.

**If you have questions about your ball machine, DO NOT contact your dealer; please call Lobster Sports directly at 800.210.5992**

Serial Number: \_\_\_\_\_

Purchase Date: \_\_\_\_\_


## **!** WARNING

TO AVOID INJURY:

- Keep face out of ball path - balls can shoot out from opening at any time.
- Use only for tennis practice with conventional tennis balls.
- Turn off the machine when leaving it unattended or before performing maintenance tasks.
- Never place body parts or objects into machine.
- Never operate with parts removed.
- Never add balls while machine is running.
- Never put wet tennis balls in machine.



7340 Fulton Avenue  
North Hollywood, CA 91605  
tel 800.526.4041 fax 818.764.6061

  
www.lobstersports.com  
sales@lobstersports.com  
support@lobstersports.com

# MACHINE SETUP

## Intended Use

This tennis ball machine is intended to be used in a dedicated tennis facility. For safety reasons, players should stand on the opposite side of the tennis net at a minimum of 35 feet away from the machine. This tennis ball machine is designed to throw tennis balls only.

## Unpack and Assembly

Remove the machine from the box. Keep the box along with the packing materials in case the machine needs to be shipped back to the factory.

### Assembly:

- Detach the hopper.
- Flip the hopper and reattach by pushing the hopper on to the case knobs, starting with the front knob (side furthest from handle), then attach the hopper to the back knob.
- **Do not remove the wire deflectors.**
- Confirm that the Main Power switch is in the ON position. The main power switch can be found on the left side of the metal box directly below the control panel. There is no need to remove the red case to find this switch.

## Handle Operation


To raise the handle, simply pull up on the end until it locks in place. To fold the handle, move the switches on the inside of the hinges to the unlock position and apply light pressure to the handle until it begins to fold. The handle can now be lowered into its storage position.

## Transporting

The handle is provided to push or pull the machine. The lower part of the handle is designed to easily go up/down stairs but, it can also wear the metal and cause premature failure if care is not used. Be aware of steps or rough surfaces that may bend or damage the underside of the machine.

To prepare the machine for transport in your vehicle, invert the hopper to cover the machine and fold the handle. The machine weighs approximately 46 lbs and may be lifted into a vehicle by one or two people. Use the molded handholds on the underside of the machine to lift and carry the machine.

# ELITE GRAND FIVE LE CONTROL PANEL





- A. Power** – Push and hold the POWER button to turn the machine on. Battery level is shown at startup. Both the horizontal and vertical motors will perform functional checks to calibrate the machine when it is turned on or off.
- B. Remote** – Push this button to turn on/off the remote control receiver.
- C. Drills** – 12 different pre-programmed sequences that mimic opponent play.
- D. Program** – Press to create customized drills.
- E. Manual** – Machine will continuously throw a certain shot to a specific location.
- F. Menu Buttons** – Used to scroll through the menu options to be selected and adjusted. A cursor on the LCD will highlight the current selection.
- G. Settings** – Used to adjust a highlighted option on LCD screen.
- H. 1-18 Numbered Buttons** – Used to select desired position for ball to land in program mode. (More detailed information can be found in the program section.)
- I. Test** – Used to align your machine for proper ball placement on the court.
- J. Play/Pause** – Press to play and pause the machine.
- K. Random** – Random throws using variations of speed, spin and trajectory.
- L. 2-Line** – Alternating forehand and backhand shots, with varying degrees of difficulty.
- M. Sweep** – Throw balls randomly across the WIDTH (left-right) of the court.
- N. Depth** – Throws balls randomly the LENGTH of court, from short to deep in one row.
- O. Main Power Switch** – Main power cut off. (This switch is located on the left side of the metal box directly below the control panel).
- P. Charger Connector** – Used to charge your battery.






# OPERATING INSTRUCTIONS ELITE GRAND V LE

## Court Placement / Test Button

Your Lobster elite grand five limited edition is a computerized tennis machine and has been designed to keep the ball in the full singles court.

- Ensure that the main power switch is in the up or on position.
- Start by placing the machine with the white Line Marker positioned over the baseline, at the court's center mark.
- Power on  the machine and allow it to go through a self test.
- Push the  button. One tennis ball should be thrown over the net to land within a 2 foot area of the opposite side of the court where the service and center lines converge, just as depicted by the diagram to the right.



- If the test ball lands outside of the 2 foot radius, long or short use the  and  SETTINGS buttons to adjust the distance in .5 foot increments. If the ball should fall outside of the area left or right, nudge the front of the machine slightly to the left or right, as needed. Retest and make adjustments as necessary.
- Once the test is complete, press any one of the oval shaped function buttons to choose the desired mode of play, then press the play button to run that mode.

## Random

Your Lobster machine will randomly throw balls on the court using variations of speed, spin and trajectory.

- Feed – Adjust between random and 2 - 9 second intervals.

## 2-line Function

- Speed – Choose from 50 to 80 MPH in 5 mph increments.
- Spin – Increase and decrease top and back spin up to three levels.
- Depth – A (Deep), B (Mid), C (Short), Random (the depth will constantly change).
- Feed – Adjust between random and 2 - 9 second intervals.

## Sweep

Your Lobster machine will throw balls randomly across the width of the court. Shot parameters remain at the same setting during play and include:

- Depth – A (Deep), B (Mid), C (Short), Random (the depth will constantly change).
- Speed – Choose from 50 to 80 MPH in 5 mph increments.
- Spin – Increase and decrease top & back spin up to 3 levels.
- Feed – Adjust between random and 2 - 9 second intervals.





## OPERATING INSTRUCTIONS CONTINUED

### Depth DEPTH

Your Lobster machine will throw balls randomly from short to deep. Shot parameters remain at the same setting during play and include:


- Position – At the top of the LCD, choose the column you wish the balls to land in. The column number matches the buttons in the top row of your control panel.
- Speed – Choose from 45 to 75 MPH in 5 mph increments.
- Spin – Increase & decrease top & back spin up to 3 levels. (depending on speed)
- Feed – Adjust between random and 2 - 9 second intervals.

### Manual MANUAL

Press the MANUAL Button to practice one particular shot repetitively. The machine will pause while you make your adjustments. Use  /  Menu buttons to select location and shot parameters. Use  / 

SETTINGS buttons to increase or decrease value of the selected menu option.

- Speed – Choose from 35 to 80 MPH in 5 mph increments.
- Elevation – Adjust elevation between 2 and 80 degrees in 1 degree increments to change depth of the ball thrown on the court.
- Spin – Increase and decrease top and back spin up to three levels.
- Angle – Choose position along baseline. 0 is center court with positive numbers moving to the right and negative numbers moving to the left.
- Feed – Adjust between 2-9 second intervals, or scroll down to random setting.

When you are satisfied with your adjusted settings press the  Play/Pause button to start your session.

**PLEASE NOTE that not all combinations of SPEED, SPIN, FEED and DEPTH will work in conjunction with each other.**



# OPERATING INSTRUCTIONS CONTINUED

## Program








The Program function allows you to create your own drills and set up your own training exercises. You may create sequences of shots with anywhere from 1 to 6 balls that will cycle. This allows for many more combinations that will always give you new challenges. There are limitations to what the machine can do...**please read this carefully.**

- The serving wheels can speed up faster than they can slow down. Fast shots followed by slow shots or drastic changes in spin will produce shots out the back of the court if used with fast feed rates. If you wish to use faster feed rates, keep your changes in speed and spin incremental. A good guide is not to change the speed more than your feed rate times 5 in miles per hour (treat each level of spin as 5 MPH).

**As an example :** A feed rate of 4 sec will let you have up to 20mph of change or 4 levels of spin.

- Certain combinations of speed and spin will not stay within the court. If a setting will not produce a viable shot, the display will blink to tell you that the shot is not possible and remain at the previous setting.
- When you have filled up the 6th shot in a program, selecting next will automatically take you to the overall program screen.

## Create Your First Personal Program

1. Press the PROGRAM button 
2. The screen will prompt you to select a location for your first shot. Press any of the 1 - 18       buttons to advance to the Shot Parameters Screen.
3. The machine is programmed to throw one ball to the location selected. You may now adjust the shot parameters for this shot:
  - Speed – Choose from 40 to 80 MPH in 5 mph increments.
  - Spin – Increase and decrease top and back spin up to three levels.
  - Feed – Adjust ball feed rate between random and 2 - 9 seconds. (applied to the entire program)





### SHOT LOCATION SCREEN

P#1 SHOT#1 LOC ?  
Press a location  
To prgm shot, or  
Press – to erase

### SHOT PARAMETERS SCREEN

P#1 SHOT#1 LOC?\*  
SPEED: 70 MPH  
Spin :0 FEED: 4  
Next + Back -

\*will display your selected location

4. When the shot is satisfactory, use the menu buttons  /  to highlight the "Next + Back -" line. Press  to choose the location and shot parameters for the next shot in your drill or  to return to overall program screen.

## OPERATING INSTRUCTIONS CONTINUED

5. Selecting and running a drill can be done from the Overall Program Screen:

- The top line displays your Program number. You can change the Program number from 1-6 by highlighting the top line with the menu buttons  $\uparrow$ / $\downarrow$  and adjusting the number with  $\oplus$ / $\ominus$  settings buttons.
- Line 2 allows you to edit or view the settings of an existing shot in the Program
- Line 3 and 4 will show you the court location of each ball thrown. One number for each ball. You may have up to six balls in a program.
- Pressing Play  $\circlearrowright$  at any time on this screen will run the Program.

OVERALL PROGRAM SCREEN

```
P# 1 PLAY TO RUN
SHOT: 2 EDIT: NO
LOCS 3 12 18 5
      2 11
```

### Editing An Existing Program

Once you have created a program you may want to adjust or completely redesign any aspects of the program.

1. If you are not already in the program function, press the Program button  $\textcircled{\text{PROGRAM}}$  to display the Overall Program Screen.
2. First use the  $\oplus$ / $\ominus$  settings buttons to select the program you wish to adjust.
3. Next use the menu buttons  $\uparrow$ / $\downarrow$  to highlight SHOT then adjust the number to reflect which shot in the sequence you wish to adjust (1st, 2nd, 5th...)
4. Highlight edit and press the  $\oplus$  button to change to a yes. This will take you to the Select Location Screen.
5. The current location of this shot is now displayed in the upper right corner. If you are satisfied with the location, press the same number to select it again and you will advance to the shot parameters screen which will display your current settings.
6. If you chose another location, the defaults will reset.
7. You can remove a shot from the drill by pressing the  $\ominus$  button. This will return you to the Overall Program Screen and the drill will run with one less shot.

### Drills

$\textcircled{\text{DRILLS}}$

The drills button allows for pre-programmed training exercises. Each of the six custom designed court drills consists of 6 sequential shots in a designated pattern combining court location, ball speed, and spin. To adjust difficulty, the feed rate can be set to fixed 2 - 9 seconds or RANDOM that will constantly change the feed rate. Use the  $\oplus$ / $\ominus$  SETTINGS buttons to adjust this rate. Low feed settings will have a short pause between cycles.





# PLAYSTYLE DRILL INSTRUCTIONS


## PLAY STYLE DRILLS

Each of the 12 drills consists of 6 shots in a designated pattern, changing location, ball speed and spin. To alter difficulty, the feed rate can be adjusted.


**Grinder** – Six ball drill utilizing the full back court with different types of spin.

**Power Baseliner** – Six ball drill that utilizes the full back court with little spin and more ball speed.


**All-Courter** – Six ball drill that utilizes both the front and back court with some top spin and less ball speed.



**Grinder**



**Power Baseliner**




**All-Courter**


**Approach** – Six ball drill emphasizing the approach from behind the baseline into the front court with balance and speed.

**Attack/Defend** – Six ball drill designed to teach a player to move in all directions from the baseline.


**Forehand Plus** – Six ball drill challenging the player to maintain dominant court position by using their forehand for every shot.



**Approach**



**Attack / Defend**




**Forehand Plus**

## PLAYSTYLE DRILL INSTRUCTIONS CONTINUED


**Beginner** – Six ball drill to help beginners improve and build confidence.

**Intermediate** – Six ball drill that will help intermediates improve their court coverage and execute a variety of shots.


**Advanced** – Six ball drill for advanced players to develop higher shot tolerance and learn to quickly identify 'opportunity' balls that can be attacked.



**Beginner**



**Intermediate**




**Advanced**


**Moon Baller** – Six ball drill that utilizes a high arc over the net with moderate to heavy top spin.

**Slicer** – Six ball drill with backspin or underspin that utilizes a low arc over the net.


**Lefty** – Six ball drill that simulates strong forehand groundstrokes and strong backhand volleys.



**Moon Baller**



**Slicer**





**Lefty**

# OPERATING INSTRUCTIONS - REMOTE CONTROL

## Remote Control

The remote consists of fifteen buttons and allows you to operate many of the functions on your ball machine from a distance.



- Press the  REMOTE button located on the control panel to activate the remote. When the LED is lit the machine will accept commands from your remote controller.
- **PLAY/PAUSE** button will start and stop the machine at any time.
- **TEST** - Allows you to calibrate your machine.
- **RANDOM** - Press button to activate the fully random function.
- **2-LINE** - Press button multiple times to scroll through the narrow, medium, and wide settings for the 2-line functions.
- **DRILLS** - Press button to scroll through the pre-programmed drills.
- **SWEEP** - Press multiple times to scroll through the short, mid, deep and random settings for the sweep function.
- **DEPTH** - Press button multiple times to scroll through short, mid, deep and random settings for the depth function.
- The 8 black buttons are used to change shot parameters on the fly for the presets.
  - **Speed** – Adjust the ball speed for 2-line, sweep, depth, and manual presets.
  - **Spin** – Adjust the top or bottom spin for 2-line, sweep, depth, and manual presets.
  - **Feed** – Adjust the ball interval for all settings.
  - **Elevation** – Adjust the elevation for 2-line, manual, and test function.

Using the remote while a drill is running will cause the next shots parameters to change temporarily. Doing so may cause shots to land in unplayable areas.

## CHARGING INSTRUCTIONS

### Charging the Battery with the Fast Charger or Premium Fast Charger

Trickle charge technology ensures the battery will not be overcharged and can be left connected indefinitely.

- For the **Fast Charger**, connect the cord into the charger jack on the left of the control panel. Plug the charger into a live electrical outlet. The battery will be charged in 3-9 hours.
- For the **Premium Fast Charger**, connect the cord into the charger jack on the left of the control panel. Plug the charger into a live electrical outlet. The battery will be charged in 1-3 hours.
- An orange light on either charger indicates the battery is charging.
- A green light indicates the battery is fully charged.
- For optimal capacity, charge the battery with the fast charger after each use.

### Battery Capacity

Battery level is shown when the machine starts up as Full, High, Medium, or Low! When the machine is not in use (i.e. during the winter season or when in storage) charge the machine **every month**. Before storing the machine, ensure the battery is fully charged and the main power switch is off in the down position. Never let the machine go uncharged for more than one (1) month. The most common reason for a dead battery is a dead AC outlet. Ensure the machine is connected to a live AC outlet and is receiving a charge. The most common reason for shortened battery capacity and life is chronically undercharging the machine.

FOR UNLIMITED PLAY YOU MAY PURCHASE LOBSTER SPORTS' EXTERNAL AC POWER SUPPLY. Please call Customer Service at 800.526.4041 or visit [www.lobstersports.com](http://www.lobstersports.com)



## TROUBLESHOOTING

### Machine Doesn't Power On

The main power switch may be off. The battery may need to be charged. The battery wires may be disconnected or loosened.

- Make sure the MAIN POWER switch on the machine is in the off position and ensure there are no balls in the machine.
- Undo the four screws on the control panel and gently pull back. (Be careful not to touch the electronic board directly)
- Follow the red and black wires from the battery terminals to the control board. If they are loose, reconnect.

**If you have questions about your ball machine, DO NOT contact your dealer; please call Lobster Sports directly at 800.210.5992**

### Machine Error

The electronics are programmed to help the user diagnose his/her machine.

Error messages will appear on the LCD screen when the machine is turned on.

If there is no obvious problem, turn the machine off and back on again to check error message. If the error message continues, call Lobster Customer Service at 800.526.4041.

## CUSTOMER SERVICE

Since 1970, Lobster Sports has been dedicated to providing outstanding customer service. To this end, we invite our customers to contact our Customer Service Department at **800.526.4041** anytime between 8:00am - 4:30pm PST, Monday through Friday. After hours, please leave a voice message or email us at [support@lobstersports.com](mailto:support@lobstersports.com)

### Shipping Damage

If an order arrives with shipping damages, contact Customer Service to coordinate sending a replacement. If a replacement part can resolve the issue, Lobster will ship the part immediately. If not, a damage call tag will be issued. Upon pick up of the damaged machine, the customer must call in the pick-up tracking number and a replacement will be shipped immediately.

### Mis-Shipments

Lobster Sports maintains the highest manufacturing and shipping quality standards and strives for 100% accuracy. However, in the event an order is not correct please contact Customer Service to rectify the situation.

## MAINTENANCE

### Storage

Never store the machine outside. Exposure to rain and snow will shorten machine life. Store the machine in a clean, dry location with the Main Power off. Never store the machine in a closed car trunk where temperatures can reach 180 degrees. Extreme temperatures and conditions can affect the machine's electronic board and battery. Exposure to rain and snow will damage the electronics.

### Cleaning

Turn Main Power OFF when cleaning the machine. Outside of machine may be wiped down with a mild detergent. Inside of machine may be vacuumed to remove tennis ball fuzz. The Lobster storage cover is ideal to protect your machine from the elements.

### Ball Consistency

The consistency of ball throws is dependent on the consistency of the tennis balls you use. Consistent balls will produce consistent ball throws. A mixture of new and old balls will produce inconsistent ball throws. Pressureless balls are recommended for use with a ball machine. For more information, call Lobster at 800.526.4041.

## LIMITED WARRANTY

Lobster Sports warrants that each Lobster Sports ball machine purchased will be free from defects in material and workmanship for 2 years from the date of purchase except for the battery and server wheels which are warranted for 6 months. Demonstration models and reconditioned machines have a 1 year warranty. Said warranty to be determined by Lobster Sports at time of purchase. Any part of ball machine which proves to be defective in material or workmanship within the 2 year warranty period will be repaired or replaced at Lobster Sports' option with a new or functionally operative part. Warranty extends only to the original customer and may be enforced only by such person.

This warranty does **not** cover the following conditions: A) Damage resulting from misuse, neglect, alteration, accidents, tampering, abuse, fire, war, insurrection, civil disorder, flood, acts of God or any other casualty; B) Failure of Customer to properly follow operating instructions provided by Lobster Sports at time of delivery; and C) Damage caused by use on circuits or voltages other than indicated on the applicable nameplate.

**This limited warranty is in lieu of all other express warranties. Any implied warranties of merchantability and fitness for a particular purpose shall coincide in duration with the 2 year limited warranty. The exclusive remedy of the Customer hereunder shall be repair or replacement as stated above. Under no circumstances shall Lobster Sports be liable to the Customer or any other person for incidental or consequential damages of any nature, including, without limitation, damage for personal injury or damages to property; and however occasioned, whether alleged as resulting from breach of warranty by Lobster Sports, the negligence of Lobster Sports.**

No agent, employee or representative of Lobster Sports or any other person is authorized to modify this warranty in any respect. This warranty gives you specific legal rights and you may also have other rights, which vary, from state to state.

This limited warranty is void unless Customer completes and returns the attached **warranty response form** to Lobster Sports within 30 days of receipt of the ball machine.



**WARRANTY REGISTRATION** - To validate warranty, fill out card and send back via mail or email to [warranty@lobstersports.com](mailto:warranty@lobstersports.com). If you bought from a authorized dealer, please also include proof of purchase. (\*Required Fields)

Machine Serial Number\* \_\_\_\_\_

Name\* \_\_\_\_\_ Email\* \_\_\_\_\_

Mailing Address\* \_\_\_\_\_ City\* \_\_\_\_\_ State\* \_\_\_\_\_ Zip\* \_\_\_\_\_

Phone\* \_\_\_\_\_

Purchase Date\* \_\_\_\_\_ Where Purchased\* \_\_\_\_\_

**How did you learn about Lobster?** (circle) Lobster Website Google Yahoo MSN Pro Friend Dealer  
Dealer Website \_\_\_\_\_ Tennis Magazine Tennis Week Magazine Other Magazine/Search Engine \_\_\_\_\_

**What attracted you to this product?** (circle) Quality Design Price Reputation Previous Customer Portability Better Features

**Income** (circle) \$40-60K \$60-80K \$80-\$100K \$100-\$120K \$120-140K \$140-\$160K \$160-\$180K \$180-200K \$200K+

**Age** (circle) 15-25 25-35 35-45 45-55 55-65 65-75 75-85 85+ **Occupation** \_\_\_\_\_

**OPTIONAL EXTENDED WARRANTY\*\*** Please send in a separate envelope within 60 days of purchase.

Please select from the following:		Credit Card # _____	Expiration Date _____
<input type="checkbox"/> 1 Year	.....\$65	Verification Code (last 3 digits in signature bar) _____	Select (circle) Visa Mastercard Discover Card
<input type="checkbox"/> 2 Years	.....\$110	Authorization Signature _____	
<input type="checkbox"/> 3 Years	.....\$149		

Lobster Sports warrants each Lobster elite machine purchased will be free from DEFECTS IN MATERIAL AND WORKMANSHIP for the extended period specified above past the normal 2 year limited warranty. The extended warranty period will run consecutively from the warranty period determined at time of purchase. **It does not cover parts worn under normal use**, specifically the battery and the server wheels.  
\*\*Extended warranties only apply to machines located in the United States.

place  
stamp  
here



**LOBSTER**<sup>®</sup>

7340 Fulton Avenue  
North Hollywood, CA 91605