

grand remote for Apple

SET-UP & START-UP GUIDE



Apple, the Apple logo, Apple Watch and iPhone are trademarks of Apple Inc., registered in the U.S. and other countries. App Store is a service mark of Apple Inc., registered in the U.S. and other countries.

How to turn your Apple device into a remote control

If you have questions about your machine, DON'T contact your dealer; please call Lobster Sports directly at 800.210.5992

1. Download the **Lobster grand remote control** app from the App Store.[®]
2. Turn your ball machine on and press the REMOTE button on the control panel.
3. On your device, go to the SETTINGS button and click on "Wi-Fi". A network called "Lobster Sports(x)" will be detected. Select this network.
4. Open the **Lobster grand remote control** app on your device and allow up to 90 seconds for your device and machine to sync — they are connected when the remote CONNECT/DISCONNECT button says DISCONNECT.
5. When using Apple Watch, the iPhone must stay awake. To change awake settings, navigate to Settings>Display & Brightness>Auto-Lock>Never.
6. In the case of a disconnect, click the CONNECT button to reconnect.

lobstersports.com
7340 Fulton Avenue
North Hollywood, CA 91605



tel 818.764.6000
toll-free 800.526.4041
support@lobstersports.com