



Repair Instructions

Replacing and Installing a Rubber Foot.

Elite Models that Apply: Elite Freedom, Liberty, 1, 2, 3, Pickle and Pickle 2 machines

Step	Description	Tools	Picture
1	<p>If the rubber foot came off, but the screw is still attached to the platform (and not bent out of shape), then you should be able to remove the old rubber foot, and screw on the new foot by hand. If the screw is bent, or broken, then you will need to remove the platform to install the new screw and rubber foot.</p>		
2	<p style="text-align: center;">Removing The Case</p> <p>Step 1.) Unscrew the (6) Phillips-head screws along the bottom of the red case where it attaches to the chassis of the machine. (2-front, 2-rear, one on each side)</p> <p>Step 3.) Lift the red case off the chassis and set it aside.</p>	<p>Phillips Screw Driver</p>	 <p>Case Screws (Front & Rear)</p> <p>Case Screws (Side)</p> <p>Case Removed</p>
3	<p style="text-align: center;">Removing The Platform</p> <p>Step 1.) Tilt the machine on its side, and use a 1/8" Allen to remove the black shoulder bolt as shown in the image below.</p>	<p>Phillips Screw Driver</p> <p>9/16" Crescent Wrench</p> <p>9/16" Wrench</p> <p>1/8" Allen</p>	 <p>Platform Shoulder Bolt link location.</p>

Repair Instructions

Replacing and Installing a Rubber Foot.



Step 2.) Using a 9/16” crescent wrench, and a 9/16” wrench, unscrew the bolt in the center of the Platform which is holding the Platform to the bottom of the machine.

Step 3.) With the Platform detached, position it so that the 4 rubber feet are pointing up.



Platform with Nut removed.

Installing the Rubber feet

Step 1.) Unscrew the rubber foot or feet that need to be replaced. Using a hammer, tap on the screw that is broken or bent until it pops out.

Step 2.) Place the screw through the hole so that the threading is pointed up like the rubber feet.

Step 3.) Fasten the new rubber feet to the newly inserted screw and rotate clockwise until the foot is tight.








Foot being fastened to platform.



Rubber feet installed on platform.

Repair Instructions

Replacing and Installing a Rubber Foot.

	<p style="text-align: center;">Re-attaching the Platform the Chassis</p> <p>Step 1.) Carefully line up the platform with the Chassis, so that the Line Marker is in the front of the machine, and the link is on the left hand side. Fasten the link(s) together (see image at the right hand side) using the black shoulder bolt.</p> <p>Step 2.) Push the ½ inch platform bolt thru the bottom of the platform, so that the threaded edge is popping out of the top/middle of the chassis.</p> <p>Step 3.) Put the Battery Negative Ground Loop over the threads of the ½ inch platform bolt, and cap it off with the bolt.</p>		 <p>Platform Shoulder Bolt link location.</p>  <p>Ground Wire Placed over ½ inch Platform Bolt.</p>
	<p style="text-align: center;">Re-attaching The Case</p> <p>Step 1.) Lift the red case and lower until it is covering the whole Chassis of the machine.</p> <p>Step 2.) Screw the (6) Philips-head screws along the bottom of the red case where it attaches to the chassis of the machine. (2-front, 2-rear, one on each side)</p>		 <p>Case Removed</p>  <p>Case Screws (Front & Rear)</p>  <p>Case Screws (Side)</p>
	<p>Contact Lobster Sports Support at 1-800-526-4041 ext.14 If you have any questions or you need to order a</p>		



Repair Instructions

Replacing and Installing a Rubber Foot.

replacement foot contact Lobster Sports Support at 1-800-526-4041 ext.1003.

How to Order Elite Replacement Parts	Elite Parts
<p>Website: http://www.lobstersports.com Email: sales@lobstersports.com Phone: 800.526.4041 Fax: 818.764.6061 We accept Visa, MasterCard or Discover & PayPal</p>	<p>For Elite Freedom, Liberty, 1, 2, 3, Pickle and Pickle 2 machines: EAF3 Rubber Foot</p>