

QUICK START-UP GUIDE ELITE MODELS 1-3

If you have questions about your machine, DON'T contact your dealer; please call Lobster Sports directly at 800.210.5992

1. Place the machine with its white plastic line marker directly above the baseline and make sure the machine is centered over the center mark of the baseline.
2. Lift off the ball hopper, flip upside down, and place on top of machine. Press down to make sure ball hopper is secure.
3. Put 3-4 balls in machine hopper and wait 20 seconds for the machine to start feeding. Confirm the elevation, speed and spin are appropriate; adjust if necessary.
4. Once you have set the machine up properly, turn the machine off and fill hopper with tennis balls. Turn on the machine using the on/off switch on the control panel.
5. The ball feed has a 20 second delay allowing you time to get to the other side of the court before the first ball throw.



QUICK START-UP GUIDE ELITE MODELS 1-3

If you have questions about your machine, DON'T contact your dealer; please call Lobster Sports directly at 800.210.5992

1. Place the machine with its white plastic line marker directly above the baseline and make sure the machine is centered over the center mark of the baseline.
2. Lift off the ball hopper, flip upside down, and place on top of machine. Press down to make sure ball hopper is secure.
3. Put 3-4 balls in machine hopper and wait 20 seconds for the machine to start feeding. Confirm the elevation, speed and spin are appropriate; adjust if necessary.
4. Once you have set the machine up properly, turn the machine off and fill hopper with tennis balls. Turn on the machine using the on/off switch on the control panel.
5. The ball feed has a 20 second delay allowing you time to get to the other side of the court before the first ball throw.



QUICK START-UP GUIDE ELITE MODELS 1-3

If you have questions about your machine, DON'T contact your dealer; please call Lobster Sports directly at 800.210.5992

1. Place the machine with its white plastic line marker directly above the baseline and make sure the machine is centered over the center mark of the baseline.
2. Lift off the ball hopper, flip upside down, and place on top of machine. Press down to make sure ball hopper is secure.
3. Put 3-4 balls in machine hopper and wait 20 seconds for the machine to start feeding. Confirm the elevation, speed and spin are appropriate; adjust if necessary.
4. Once you have set the machine up properly, turn the machine off and fill hopper with tennis balls. Turn on the machine using the on/off switch on the control panel.
5. The ball feed has a 20 second delay allowing you time to get to the other side of the court before the first ball throw.



QUICK START-UP GUIDE ELITE MODELS 1-3

If you have questions about your machine, DON'T contact your dealer; please call Lobster Sports directly at 800.210.5992

1. Place the machine with its white plastic line marker directly above the baseline and make sure the machine is centered over the center mark of the baseline.
2. Lift off the ball hopper, flip upside down, and place on top of machine. Press down to make sure ball hopper is secure.
3. Put 3-4 balls in machine hopper and wait 20 seconds for the machine to start feeding. Confirm the elevation, speed and spin are appropriate; adjust if necessary.
4. Once you have set the machine up properly, turn the machine off and fill hopper with tennis balls. Turn on the machine using the on/off switch on the control panel.
5. The ball feed has a 20 second delay allowing you time to get to the other side of the court before the first ball throw.

