





Elite Grand Series T.S.
My Machine Says Over-Current Feed Motor Error.
My Machine Says Feedback Feed Motor Error.

Objective: To find out if the board or motor is causing the error.

Action		Picture
<p>The more common statements regarding over-current feed issues are...</p> <p style="padding-left: 40px;">“My machine has an Over-current error message.” “`My Machine has an Feedback error message.” “My machine feed does not spin.”</p> <p>This indicates one of the following: There is a ball jam. (See Step 1. Ball Jam Guide) The feed motor is not connected properly. (See Step 2. Checking the Feed Motor). The feed motor is bad. (Contact Customer Service Support at 1-800-526-4041 ext.14).</p>		
<p style="text-align: center;"><u>Ball Jam Guide</u></p> <p>Step 1.)</p> <ol style="list-style-type: none"> 1. Turn your machine off. 2. Take all balls out of the hopper and remove the hopper. 3. Using needle nose pliers, remove the Deflector Wires, starting with one end and lifting it out of the hole, and then spinning it around and unhooking the other end. 4. Spin the carousel (or index wheel) around clock-wise until the stuck balls pop out from underneath the carousel. 5. Remove the ball(s). 6. Put the carousel back onto the feed motor shaft, and turn counter clock-wise until tight. 7. Put the deflector wires back on. <p>If the problem is not resolved, continue to Step 2.</p>		 <p style="text-align: center;">Removing Deflector wires.</p>  <p style="text-align: center;">Carousel taken off after being turned CLOCKWISE.</p>

Checking the Feed Motor

Step 2.)

1. Unscrew control panel screws, and allow the control panel to GENTLY drop until it is held in place by the wires.
2. Locate the feed motor wires and make sure they are plugged into the Feed Terminal. (The Feed Terminal is located beside the bottom server wires. It is a white rectangle shaped box that says “Feed” on the green board in front of it.)
3. If the Feed is disconnected, connect it, and screw the panel back on.
4. Make sure to check the red and black wires connected into the feed housing (The white clip at the end of the feed motor that plugs into the Feed Terminal.), are all the way into the housing.

If the problem is not resolved, please contact Lobster Sports Customer Support at 1-800-526-4041 ext.14 and they will help issue you a Repair or Warranty Repair RA.



Feed Tab (3rd one to the right.)