


Replacing and Installing an Pickle 2.10 Board

Step	Description	Tools	Picture
	<p>Models that Apply: Pickle 2 (with 10 function remote).</p> <p>This instruction is to help guide you through installing a new control panel for your Pickle 2 (with 10 function remote) model machine. Please use the image as reference to ensure you have the correct control panel. If your panel says "elite Liberty" or "elite 3" on the front lower left-hand side of the panel or looks differently on the circuit board section (shown in the 2nd picture), please contact Lobster Sports Customer Service at 1-818-764-6000 for a Return Authorization (<i>they might ask for a picture by e-mail as proof, and your machine serial number which is located underneath the machine on a white sticker readings ELO*-*****</i>).</p> 	<p>Phillips Screw Driver, and needle nose pliers</p>	

Replacing and Installing an Pickle 2.10 Board



Unscrewing You Control Panel


Step 1.) Using a Philips screw driver, unscrew the 4 control panel screws that are holding the old panel to the back of the red case (in between the lower folding handle). *Note: If your control panel was sent under warranty with-in the first year of ownership of the machine, it is likely that you sent the old control panel back, and there is no old control panel to be removed.*

Step 2.) Disconnect the Positive (red) and Negative (black) wire´s from the battery terminal.

Step 3.) You can simply disconnect 1 wire from the old control panel, and reconnect it on the new control panel, one wire at a time, until all of the old wires have been transferred onto the new control panel. In order to help you, we have also showed were these wires connect and what they look like. The rest of the guide will show this in sections of small wires to make this task easier to follow.



4 Control Panel Screw locations.



Battery Terminal Wires

Replacing and Installing an Pickle 2.10 Board

Motor Wire Connections

This guide will show the wires with a lower-case letter, and the image of where these wires connect to on the new panel in Capital letters. Each lower-case letter matches its Capital version on the wire connection diagram.

ELOP2

Motor Connections

- a. Top Server Motor (marked in Red)



- b. Bottom Server Motor (marked in Blue)



- c. Feed Motor (marked in Dark Red)



- d. Elevation Motor (marked in Green)



- a. Top Server motor wires (black and red marked by the red square).



- b. Bottom Server Motor (marked by a blue square).



- c. Feed (marked in dark red)



- d. Elevation (marked in green)



- e. Sweep (marked in orange)


Replacing and Installing an Pickle 2.10 Board



e. Sweep Motor (marked by Orange)



Use the image below showing where the wires connect to on the New circuit board.




Pickle 2.10 Panel with Labels.


Replacing and Installing an Pickle 2.10 Board

Power Wire Connection


- f. Battery Negative Wire (black) from battery terminal to "Bat Neg" connection tab on green board. Attached black pigtail wire to corner ground screw on the back of control panel. (Marked by **Off Blue**)




- g. Battery positive wire (red) from battery terminal to tab on back of the reset switch. (Marked by **Brown**)



- h. Ground wire (black) from feed motor (additional black wire attached to screw on feed motor) to corner ground screw on back of control panel. (Marked in **Gold**)



f. Battery Negative wire from battery terminal (marked in off blue)



g. Battery Positive wire (red) on reset switch. (marked in brown)




h. Ground Wires (marked in gold)

Replacing and Installing an Pickle 2.10 Board



Use the image below showing where the wires connect to on the New circuit board.



Pickle 2.10 Panel with Labels.


Charger Jack Connection

- i. XLR Charger Jack black (negative) wire to one of the tabs labeled "Bat Neg" on green board. (Marked in Light Green)



- i. XLR Charger Jack (black wire negative). (Marked in Light

Replacing and Installing an Pickle 2.10 Board



j. XLR Charger Jack red (positive) wire to the prong on the reset switch. (Marked in Purple)



Note: The remote connection ONLY applies if you have an elite 10-function remote or elite 10-function Wi-Fi receiver with your machine.



k. Remote Control Receiver (multiple wire connector) if included, to connection labeled "Remote 1" on green

Green)



j. XLR Charger Jack (red wire positive). (Marked in Purple)



k. Remote Control (marked in Pink)



I. Wi-Fi Remote Control (marked in Light Turquoise)


Replacing and Installing an Pickle 2.10 Board

board. (Marked in Pink)



I. Remote Wi-Fi Control Receiver connects to ' 'Remote 2' ' on green board (Marked in Light Turquoise)

Use the image below showing where the wires connect to on the New circuit board.



Pickle 2.10 Panel with labels

Replacing and Installing an Pickle 2.10 Board

2-Line and Ball Detect Wires

The 2-Line wires are 3 wires braided (yellow, green, and blue) that come from the sweep motor, and have a white plug at the end that allows it to connect to the circuit board.

The Ball Detection Switch wires are 2 braided grey wires that come from under the ball chute (the slide the balls drop down before being ejected from the machine), and have a white plug at the end that allows them to connect to the circuit board.



m. Ball Detect Wires (marked in Dark Grey).



n. 2-Line Wires (Marked in Black).




m. Ball Detect Wires (marked in Dark Grey)



n. 2-Line Wires (marked in black)

Replacing and Installing an Pickle 2.10 Board

Use the image below showing where the wires connect to on the New circuit board.




Pickle 2.10 Panel with Labels

Reconnecting Your Battery Wires

Step 1.) With the new control panel installed, you can now reconnect the Black battery terminal wire to the negative section of the battery, and the Red battery terminal wire (battery positive wire) to the positive section of the battery.

Step 2.) You can now fasten the control panel to the red case, using the 4 black control panel screws.

Step 3.) It is important to ensure the new board is functioning properly, make sure to test the Power (On/Off), Elevation (Up and down) the Horizontal or Sweep (left and right) and the Feed, Speed, and Spin (All settings), as well as the Vertical Oscillation. If you have a remote with the machine it is also recommended to test it out as well. Once the machine is fully tested, we recommend checking the charger. *Note: If for what ever reason you find some function not working properly, first unscrew the control panel to ensure everything is connected properly, and no wire came disconnected in the process of reconnecting the battery wire terminals. If there are no disconnected wires, please contact Lobster Customer Service at 1-818-764-6000.*



Battery Terminal Wires



4 Control Panel Screw locations.



Replacing and Installing an Pickle 2.10 Board